



NOTES:

- ① 10° MIN. FOR WYE LATERAL CONNECTION
- ② FITTING OR LONG RADIUS BEND
- ③ SERVICE WYE WITH PIPE EXTENSION TO GRADE
- ④ WATERTIGHT END PLUG (EASILY REMOVABLE)
- ⑤ PLACE WELL COMPACTED BEDDING MATERIAL 18" UNDER WYE BRANCH, FITTING, AND UNSUPPORTED PIPE. WHEN BEDDING MATERIAL IS USED, PLACE ADDITIONAL MATERIAL TO TOP OF BEND, THE FULL WIDTH OF TRENCH.

<p>SIERRA LAKES COUNTY WATER DISTRICT</p>
<p>LATERAL AND CLEANOUT ASSEMBLY</p>
<p>SEPTEMBER 12, 2008</p>
<p>FIGURE 4</p>